




Multimedia Projector

EB-W10







EB-X10





EN	Quick Start Guide
DE	Kurzanleitung
FR	Guide de démarrage rapide
IT	Guida di avvio rapido
ES	Guía de inicio rápido
PT	Guia de Referência Rápida
NL	Introdactiehandleiding
DA	Introduktion
FI	Pika-aloitusopas
NO	Hurtigveiledning
SV	Snabbstartsguide
CS	Úvodní příručka
HU	Bevezetés
PL	Przewodnik szybkiego startu
SK	Stručná príručka
BG	Ръководство за бърз старт
RO	Ghid de pornire rapidă

ET	Lühijuhend
LV	Ātrās darba uzsākšanas pamācība
LT	Trumpas pradžios vadovas
EL	Οδηγός γρήγορης εκκίνησης
TR	Hızlı Başlangıç Kılavuzu
SL	Priročnik za hitri začetek
HR	Kratke upute
MK	Прирачник брз почеток
SR	Uputstvo za brz početak
CA	Guia d'inici ràpid
RU	Руководство по быстрой установке
UK	Коротка інструкція "Початок роботи"
AR	دليل البداية السريعة
FA	راهنمای سریع برای شروع بکار
HE	מדריך לפעולה מהירה
ZHS	設定手册
ZHT	設定說明書


EN	Content of the box	ET	Kasti sisu
DE	Packungsinhalt	LV	Komplektācija
FR	Contenu de la boîte	LT	Dėžės turinys
IT	Contenuto della confezione	EL	Περιεχόμενα της συσκευασίας
ES	Contenido del paquete	TR	Kutunun içeriği
PT	Conteúdo da embalagem	SL	Vsebina paketa
NL	Inhoud van de doos	HR	Sadržaj paketa
DA	Æskens indhold	MK	Содржина на кутијата
FI	Laatikon sisältö	SR	Sadržaj kutije
NO	Innholdet i esken	CA	Contingut de la caixa
SV	Innehåll i lådan	RU	Содержимое упаковки
CS	Obsah balení	UK	Вміст упаковки
HU	A doboz tartalma	AR	محتوى الصندوق
PL	Zawartość opakowania	FA	محتویات جعبه
SK	Obsah balenia	HE	תכולת האריזה
BG	Съдържание на кутията	ZHS	包装箱内容
RO	Conținutul cutiei	ZHT	包裝箱內容





1 EB-W10

16:10



EB-X10

4:3

